



TeamCall® Audio and Video Conferencing for IBM Lotus Sametime


Start telephone and video conferences with just a single click in **Lotus® Sametime®**

Conference calls with Lotus Sametime

- 1 Participate in scheduled and ad hoc conference calls with a single click



- 2 Overview of participants and the telephone icon shows who is logged on
- 3 An active speaker icon provides feedback on who is speaking



Sametime web conferencing integration for Video and PBX


- Enables "click to join" or dial in audio conferencing for web participants
- Provides telephony / audio controls to the web conferencing host
- Integration via iLink audio conferencing bridge and SIP connection to the PBX
- Multipoint video conferencing for up to 10 concurrent participants
- Vendor-independent integration of existing video conference room systems for SIP-capable MCUs






Telephony feature integration with Sametime® web conferencing

- Users can dial in using a conference ID and pass code
- Dial out
- Disconnect participants
- Rename users
- Mute individual users or all users
- Lock the conference
- Associate audio calls with web participants
- Start and stop the conference



Audio bridge-PBX connection through SIP or S2M



Technical Requirements

- IBM Lotus Sametime Release 8.0.1 to 8.5.1
- Linux server (for the conference bridge) with LAN access and connectivity to your phone system via SIP or S2M
- TTeamCall Video USL server
- TeamCall Video clients (PCs)

TeamCall Video client-server connection